

DESCALE

CONCENTRATED PHOSPHORIC ACID DESCALER

Descale is a concentrated phosphoric acid based liquid descaler used for the removal of lime scale in automatic dishwashing & glasswashing machines, boilers, calorifiers, coffee machines, kettles, showerheads, steamers & housekeeping showerheads, sink plugs, taps etc.



PACK SIZE 2x5 Litre Box **CODE:** 0206-02x5

USAGE DIRECTIONS

For descaling single tank dishwashing machines, fill wash tank with detergent free hot water, add 2 - 5 litres of Descale and run the machine in manual mode for 10 - 15 minutes at 55°C until the scale deposits are removed. Empty tank, flush with clean water and allow to air dry. For twin tank or flight dishwashing machines, add 2 - 5 litres of Descale to each tank, and repeat process as above. To clean the final rinse end of a multi - tank dishwashing machine, use a hot solution of Descale, spray or brush area until scale dissolves, then rinse out & air dry.

For descaling water boilers, calorifiers, kettles & housekeeping showerheads, sink plugs etc use Descale between 12 - 18mls per litre of hot water, ensuring that they are thoroughly rinsed out once descaling process is completed.

For removing water marks and light scale from general kitchen & housekeeping equipment, stainless steel surfaces, tiles etc, make up a solution of Descale with 12 - 18mls per litre of hot water, wash over area with a sponge or cloth and leave for 1 minute to penetrate scale, then rinse off with plenty of fresh clean water and allow to air dry.

TECHNICAL DATA

Appearance	Green coloured liquid	pH (conc)	1.0
Odour	Irritating odour	Sg	1.20 +/- 0.5
Solubility in Water	Soluble		

CLP PICTOGRAM



Signal Word - **Danger**

CLP HAZARD STATEMENTS

H314 Causes severe skin burns and eye damage

CLP PRECAUTIONARY STATEMENTS

P102	Keep out of reach of children
P280	Wear protective gloves / protective clothing / eye protection / face protection.
P301+P330+P331	IF SWALLOWED: Rinse mouth. Do NOT induce vomiting.
P303+P361+P353	IF ON SKIN (or hair): Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower.
P305+P351+P338	IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
P310	Immediately call a POISON CENTRE or doctor.
P337+P313	If eye irritation persists: Get medical advice/attention.
P405	Store locked up.
P501	Dispose of contents/container in accordance with local regulations.

SAFE HANDLING & STORAGE

Do not mix with other chemicals. Not safe on aluminium. Protect from frost.

For full Health & Safety information please refer to Safety Data Sheet number 0206



Advantage Chemicals Institutional Ltd

Unit 9 Strensham Business Park, Strensham, Worcestershire WR8 9JZ
Tel: 01684 273299 Web: www.advchem.co.uk Email: sales@advchem.co.uk